

BROEN-LAB UNIFLEX™ FITTINGS FOR NON-BURNING 2.0 GASES / VACUUM

BROEN-LAB UNIFLEX™ FITTINGS FOR NON-BURNING 2.0 GASES / VACUUM

BROEN-LAB UNIFLEX™ FITTINGS FOR NON-BURNING 2.0 GASES / VACUUM




Content	Page
Table of Content	2
Product Overview	3
BROEN-LAB-LAB UniFlex™ PREMIUM	4-5
Fittings for Non-burnig 2.0 Gases/Vacuum	
Turret Fittings	6-7
Suspended Fittings with 90° Valves	8-9
Suspended Fittings with 45° Valves	10-11
Double Wall Fittings with 90° Valves	12
Double Wall Fittings with straight Valves	13
Wall Mounted Fittings with 90° Valves for Exposed Piping	14
Wall Mounted Fittings with Straight Valves for Exposed Piping	15
Bench or Wall Mounted 90° Fittings with Lead-in	16
Bench or Wall Mounted 45° Fittings with Lead-in	17
Suspended or Wall Mounted Straight Fittings with Lead-in	18
Fittings with Pressure Regulator	19
BROEN-LAB-LAB UniFlex <sup>™</sup> Hoses for Non-burning 2.0	Gases/Vacuum
Headworks	
Needle Headwork	
High Flow Headwork  Micro Flow Headwork	22
Accessories / Spare Parts	25
Ordering Information  BROEN-LAB-LAB UniFlex <sup>TM</sup> Fittings	26



#### THIS IS BROEN-LAB UNIFLEX™ PREMIUM

BROEN-LAB UniFlex<sup>TM</sup> PREMIUM line offers a very high quality and durability combined with the complete program, which adds up to low LCC (Life Cycle Costs). Our PREMIUM line takes the standards in the market to a higher level.



BROEN-LAB UniFlex<sup>TM</sup> PREMIUM fittings for non-burning 2.0 gases/vacuum are designed for laboratory use. The operation and the configuration of the fittings are highly adapted to the requirements of a modern laboratory. The fittings are surface treated with BROEN-LAB POLYCOAT powder coating, which is highly resistant to most chemicals, UV fading and heat (for more information please refer to "BROEN-LAB POLYCOAT" brochure).

All BROEN-LAB UniFlex™ PREMIUM fittings are delivered with a powder coated metal handle with media indication according to EN13792. As an option it is possible to get fittings with disability-friendly handle for easier operation.

BROEN-LAB UniFlex<sup>TM</sup> PREMIUM fittings for non-burning gases/vacuum incorporate a BALLOFIX® ball valve, which offers a number of advantages such as local shut-off (e.g. in connection with product service) and pre-setting for experimental purposes. As standard fittings are delivered with a fixed metal nozzle (can be removed with Allen key if needed) or a quick release coupling (hexagon coded) for easy and immediate connection and safe disconnection.

### THIS IS BROEN-LAB UNIFLEX™

BROEN-LAB UniFlex $^{\text{TM}}$  is a unique and patented connection, which allows customers to choose from various connection methods, such as hoses, Cu, PEX of Stainless Steel pipes, without changing the valve itself. It provides unique flexibility, not only for the installer, but also for the end-user. Due to the flexibility of the system, the quick installation and savings on fittings, this system offers lower TIC (Total Installed Costs).

#### WHAT IS NON-BURNING 2.0 GAS?

Non-burning 2.0 gases are typical industrial and technical gases that are 99% clean.

BROEN-LAB UniFlex<sup>™</sup> fittings for non-burning gases can be used for non-toxic, non-corrosive, non-burning 2.0 gases, such as Compressed Air, Nitrogen, Carbon Dioxide, Argon, etc.

These gases are typically commercially manufactured and sold to be used in applications within:

- laboratory and instrumentation
- chemical industry
- cutting and welding
- food processing, etc.

#### WHAT IS VACUUM?

Vacuum is a volume of space that is essentially empty of matter, such that its gaseous pressure is much less than atmospheric pressure. Vacuum is usually measured by its absolute pressure and is divided into several types (according to EN 13792):

Low Vacuum: 1000 to 1mbar
 Fine Vacuum: 1 to 10<sup>-3</sup> mbar
 High Vacuum: 10<sup>-3</sup> to 10<sup>-7</sup> mbar

Laboratory applications usually require use of suction. Suction is a flow of media into a partial vacuum, or region with low pressure. It is being used to clear surfaces, containers or tubing of residues or other materials.

#### **OUR HEADWORKS**

BROEN-LAB UniFlex<sup>TM</sup> PREMIUM fittings for non-burning 2.0 gases can be delivered with 3 different types of headworks depending on the requirements set by applications with regards to regulation of media flow.



As a standard all BROEN-LAB UniFlex<sup>TM</sup> PREMIUM fittings for non-burning 2.0 gases are delivered with a needle headwork that allows fine regulation of media flow and the valve is fully opened after  $3 \times 360^{\circ}$  rotations of a handle.

As a standard all BROEN-LAB UniFlex<sup>TM</sup> PREMIUM fittings for vacuum are delivered with a high flow headwork. If there is a need for high flow of other media than vacuum, or a valve should function as a shut-off, then it is possible to get a fitting with a high flow headwork for 2.0 non-burning gases.

In cases where media flow (2.0 non-burning gases) is close to zero and when a microscopic flow rate is required then it is an option to choose a micro flow headwork, which provides a very fine regulation of media flow.

For more information about BROEN-LAB headworks and technical details please refer to pages 24-25 in this catalogue.



With quick release coupling



The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW
Headwork: Needle Headwork: High flow
Opening/closing function: Opening/closing function:

3 x 360°

Max. working pressure: 16 bar / 232 psi

Working pressure: -1 bar to 16 bar /

1.5 x 360°

-14.5 psi to 232 psi

# Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

#### MATERIALS WITH MEDIA CONTACT

Metals: Brass

**Plastics:** PVDF, SPX (hose)

Sealing: FKM

Lubricant: Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.


Other options:

- different media
- removable hose nozzle with union nut
- disability-friendly handle (single valve only)
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)



For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative.

# Model: with fixed nozzle



Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.


#### Model: with quick release coupling


			6	6
Media	1-valve	2-valve 90°	2-valve 180°	4-valve
Compressed air	2532 056 1021-52B	2532 079 1021-52B	2532 081 1021-52B	2532 083 1021-52B
Nitrogen	2532 056 1023-52B	2532 079 1023-52B	2532 081 1023-52B	2532 083 1023-52B
Carbon dioxide	2532 056 1024-52B	2532 079 1024-52B	2532 081 1024-52B	2532 083 1024-52B
(Argon	2532 056 1025-52B	2532 079 1025-52B	2532 081 1025-52B	2532 083 1025-52B
Helium	2532 056 1026-52B	2532 079 1026-52B	2532 081 1026-52B	2532 083 1026-52B
Low vacuum (1000 to 1 mbar)	2532 057 1028-52B	2532 080 1028-52B	2532 082 1028-52B	2532 084 1028-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.



For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative.





The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW Headwork: Needle Headwork: High flow

Opening/closing function: Opening/closing function:

3 x 360° 1.5 x 360°

Max. working pressure:

16 bar / 232 psi

Working pressure:

-1 bar to 16 bar /

-14.5 psi to 232 psi

# Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

Metals: Brass

Plastics: PVDF, SPX (hose)

Sealing: FKM

Lubricant: Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)



For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative.

# SUSPENDED FITTINGS WITH 90° VALVES

# Model: with fixed nozzle


Media		1-valve	2-valve 90°	2-valve 180°	4-valve	,
(CA) Compresse	d air 2	2530 090 1021-52B	2530 092 1021-52B	2530 037 1021-52B	2530 094 1021-52B	_
Nitrogen		2530 090 1023-52B	2530 092 1023-52B	2530 037 1023-52B	2530 094 1023-52B	
© Carbon dio	xide 2	2530 090 1024-52B	2530 092 1024-52B	2530 037 1024-52B	2530 094 1024-52B	
(Ar) Argon		2530 090 1025-52B	2530 092 1025-52B	2530 037 1025-52B	2530 094 1025-52B	
Helium		2530 090 1026-52B	2530 092 1026-52B	2530 037 1026-52B	2530 094 1026-52B	_
V Low vacuu	m (1000 to 1 mbar)	2530 091 1028-52B	2530 093 1028-52B	2530 039 1028-52B	2530 095 1028-52B	_

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.

# **Model:** with quick release coupling


			9
1-valve	2-valve 90°	2-valve 180°	4-valve
2530 096 1021-52B	2530 098 1021-52B	2530 100 1021-52B	2530 102 1021-52B
2530 096 1023-52B	2530 098 1023-52B	2530 100 1023-52B	2530 102 1023-52B
2530 096 1024-52B	2530 098 1024-52B	2530 100 1024-52B	2530 102 1024-52B
2530 096 1025-52B	2530 098 1025-52B	2530 100 1025-52B	2530 102 1025-52B
2530 096 1026-52B	2530 098 1026-52B	2530 100 1026-52B	2530 102 1026-52B
2530 097 1028-52B	2530 099 1028-52B	2530 101 1028-52B	2530 103 1028-52B
	2530 096 1021-52B 2530 096 1023-52B 2530 096 1024-52B 2530 096 1025-52B	2530 096 1021-52B       2530 098 1021-52B         2530 096 1023-52B       2530 098 1023-52B         2530 096 1024-52B       2530 098 1024-52B         2530 096 1025-52B       2530 098 1025-52B         2530 096 1026-52B       2530 098 1026-52B	2530 096 1021-52B       2530 098 1021-52B       2530 100 1021-52B         2530 096 1023-52B       2530 098 1023-52B       2530 100 1023-52B         2530 096 1024-52B       2530 098 1024-52B       2530 100 1024-52B         2530 096 1025-52B       2530 098 1025-52B       2530 100 1025-52B         2530 096 1026-52B       2530 098 1026-52B       2530 100 1026-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.



 $For further information and mounting instructions please refer to www.BROEN-LAB.com\ or\ contact\ your\ local\ BROEN-LAB\ representative.$ 

With fixed nozzle





#### **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW
Headwork: Needle Headwork: High flow
Opening/closing function: Opening/closing function:

 $3 \times 360^{\circ}$   $1.5 \times 360^{\circ}$ 

Max. working pressure: 16 bar / 232 psi Working pressure:

-1 bar to 16 bar / -14.5 psi to 232 psi

# Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

Metals: Brass

**Plastics:** PVDF, SPX (hose)

Sealing: FKM

**Lubricant:** Perfluoropolyether based

### ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)



For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative

# SUSPENDED FITTINGS WITH 45° VALVES

# Model: with fixed nozzle

Media	1-valve	2-valve 90°	2-valve 180°	4-valve
(CA) Compressed air	2530 104 1021-52B	2530 106 1021-52B	2530 044 1021-52B	2530 108 1021-52B
Nitrogen	2530 104 1023-52B	2530 106 1023-52B	2530 044 1023-52B	2530 108 1023-52B
© Carbon dioxide	2530 104 1024-52B	2530 106 1024-52B	2530 044 1024-52B	2530 108 1024-52B
Argon	2530 104 1025-52B	2530 106 1025-52B	2530 044 1025-52B	2530 108 1025-52B
Helium	2530 104 1026-52B	2530 106 1026-52B	2530 044 1026-52B	2530 108 1026-52B
Low vacuum (1000 to 1 mbar)	2530 105 1028-52B	2530 107 1028-52B	2530 045 1028-52B	2530 109 1028-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton.
For other options please refer to page 26 or contact your local BROEN-LAB representative.

# Model: with quick release coupling

Media	1-valve	2-valve 90°	2-valve 180°	4-valve
(CA) Compressed air	2530 110 1021-52B	2530 112 1021-52B	2530 114 1021-52B	2530 116 1021-52B
Nitrogen	2530 110 1023-52B	2530 112 1023-52B	2530 114 1023-52B	2530 116 1023-52B
© Carbon dioxide	2530 110 1024-52B	2530 112 1024-52B	2530 114 1024-52B	2530 116 1024-52B
Argon	2530 110 1025-52B	2530 112 1025-52B	2530 114 1025-52B	2530 116 1025-52B
Helium	2530 110 1026-52B	2530 112 1026-52B	2530 114 1026-52B	2530 116 1026-52B
Low vacuum (1000 to 1 mbar)	2530 111 1028-52B	2530 113 1028-52B	2530 115 1028-52B	2530 117 1028-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.



For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative.

#### With fixed nozzle



With quick release coupling



# **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. Handle: Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

Hose nozzle: Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW

**Headwork:** Needle

**Opening/closing function:** 

3 x 360°

Max. working pressure:

16 bar / 232 psi

Headwork: High flow

**Opening/closing function:** 

1.5 x 360°

Working pressure:

-1 bar to 16 bar /

-14.5 psi to 232 psi

# Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

**Metals:** Brass

**Plastics:** PVDF, SPX (hose)

Sealing: FKM

**Lubricant:** Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- disability-friendly handle
- micro flow headwork (for technical gases)
- high flow headwork (for technical gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)

# Models

Иedia	with fixed nozzle	with quick release coupling
(A) Compressed air	2530 118 1021-52B	2530 120 1021-52B
Nitrogen	2530 118 1023-52B	2530 120 1023-52B
Carbon dioxide	2530 118 1024-52B	2530 120 1024-52B
Argon	2530 118 1025-52B	2530 120 1025-52B
Helium	2530 118 1026-52B	2530 120 1026-52B
Low vacuum (1000 to 1 mbar)	2530 119 1028-52B	2530 121 1028-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.

# **DOUBLE WALL FITTINGS WITH STRAIGHT VALVES**

With fixed nozzle



With quick release coupling



#### **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW
Headwork: Needle Headwork: High flow
Opening/closing function: Opening/closing function:

3 x 360° 1.5 x 360°

Max. working pressure:

16 bar / 232 psi

-1 bar to 16 bar /
-14.5 psi to 232 psi

### Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

**Metals:** Brass

Plastics: PVDF, SPX (hose)

Sealing: FKM

**Lubricant:** Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)

### Models






Media	with fixed nozzle	with quick release coupling
Compressed air	2532 062 1021-52B	2532 085 1021-52B
Nitrogen	2532 062 1023-52B	2532 085 1023-52B
Carbon dioxide	2532 062 1024-52B	2532 085 1024-52B
Argon	2532 062 1025-52B	2532 085 1025-52B
Helium	2532 062 1026-52B	2532 085 1026-52B
Low vacuum (1000 to 1 mbar)	2532 061 1028-52B	2532 086 1028-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton.

For other options please refer to page 26 or contact your local BROEN-LAB representative.

# WALL MOUNTED FITTINGS WITH 90° VALVES FOR EXPOSED PIPING



With quick release coupling



Models

#### **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW
Headwork: Needle Headwork: High flow
Opening/closing function: Opening/closing function:

3 x 360° 1.5 x 360°

Max. working pressure: Working pressure: 16 bar / 232 psi -1 bar to 16 bar / -14.5 psi to 232 psi

Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: PVDF Sealing: FKM

**Lubricant:** Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- disability-friendly handle
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- wall flange socket for built-in installation






Media	with fixed nozzle	with quick release coupling	
Compressed air	2530 128 1021-T	2530 134 1021-T	
Nitrogen	2530 128 1023-T	2530 134 1023-T	
Carbon dioxide	2530 128 1024-T	2530 134 1024-T	
Argon	2530 128 1025-T	2530 134 1025-T	
Helium	2530 128 1026-T	2530 134 1026-T	
Low vacuum (1000 to 1 mbar)	2530 069 1028-T	2530 135 1028-T	

Delivered with wall flange socket and compression ring fitting for OD10mm Cu-pipe For other options please refer to pages 20-21 or contact your local BROEN-LAB representative.

# WALL MOUNTED FITTINGS WITH STRAIGHT VALVES FOR EXPOSED PIPING



163mm

# **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. Handle: Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

Hose nozzle: Metal, fixed (can be unscrewed with Allen key, thread: male G3/8)

**NON-BURNING 2.0 GASES** 

**Headwork:** Needle

**Opening/closing function:** 

3 x 360°

Max. working pressure:

16 bar / 232 psi

**VACUUM / HIGH FLOW** 

Headwork: High flow

**Opening/closing function:** 

1.5 x 360°

**Working pressure:** 

-1 bar to 16 bar /

-14.5 psi to 232 psi

# Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

# MATERIALS WITH MEDIA CONTACT

**Metals:** Brass

Lubricant: Perfluoropolyether based



# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- disability-friendly handle
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- wall flange socket for built-in installation


# Models

With quick release coupling





Media	with fixed nozzle	with quick release coupling	
CAN Compressed air	2532 090 1021-T	2532 092 1021-T	
Nitrogen	2532 090 1023-T	2532 092 1023-T	
Carbon dioxide	2532 090 1024-T	2532 092 1024-T	
Argon	2532 090 1025-T	2532 092 1025-T	
Helium	2532 090 1026-T	2532 092 1026-T	
Low vacuum (1000 to 1 mbar)	2532 074 1028-T	2532 093 1028-T	



The fitting is delivered with an integrated BALLOFIX® ball valve. **Handle:** Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

**Hose nozzle:** Metal, fixed (can be unscrewed with Allen key, thread: male G3/8) or quick release coupling (hexagon coded)

Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW
Headwork: Needle Headwork: High flow
Opening/closing function: Opening/closing function:

3 x 360°

**Max. working pressure:** 16 bar / 232 psi

Working pressure: -1 bar to 16 bar /

1.5 x 360°

-14.5 psi to 232 psi

# MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: PVDF Sealing: FKM

Lubricant: Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:


- different media
- removable hose nozzle with union nut
- disability-friendly handle
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)





For other options please refer to page 26 or contact your local BROEN-LAB representative.

299 1021-52B 2530 302 1021-52B 299 1023-52B 2530 302 1023-52B 299 1024-52B 2530 302 1024-52B
200 1024 52P 2520 202 1024 52P
2330 302 1024-52B
299 1025-52B 2530 302 1025-52B
299 1026-52B 2530 302 1026-52B
_



The fitting is delivered with an integrated BALLOFIX® ball valve. Handle: Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

Hose nozzle: Metal, fixed (can be unscrewed with Allen key, thread: male G3/8) or quick release coupling (hexagon coded)

Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

**NON-BURNING 2.0 GASES VACUUM / HIGH FLOW Headwork:** Needle Headwork: High flow

**Opening/closing function:** 

3 x 360°

Max. working pressure:

16 bar / 232 psi

**Opening/closing function:** 

1.5 x 360°

Working pressure:

-1 bar to 16 bar /

-14.5 psi to 232 psi

# MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: **PVDF** Sealing: FKM

Lubricant: Perfluoropolyether based

# ORDERING INFORMATION

For standard configuration please refer to the item numbers below.

Other options:


- different media
- removable hose nozzle with union nut
- disability-friendly handle
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)



with fixed nozzle	with hexagon coded quick release coupling
2530 353 1021-52B	2530 355 1021-52B
2530 353 1023-52B	2530 355 1023-52B
2530 353 1024-52B	2530 355 1024-52B
2530 353 1025-52B	2530 355 1025-52B
2530 353 1026-52B	2530 355 1026-52B
2530 354 1028-52B	2530 356 1028-52B
	2530 353 1021-52B 2530 353 1023-52B 2530 353 1024-52B 2530 353 1025-52B 2530 353 1026-52B

Fittings are delivered with a 700mm SPX hose with OD10mm inlet conneciton. For other options please refer to page 26 or contact your local BROEN-LAB representative.

# SUSPENDED OR WALL MOUNTED STRAIGHT FITTINGS WITH LEAD-IN



# **SPECIFICATIONS**

The fitting is delivered with an integrated BALLOFIX® ball valve. Handle: Metal, BROEN-LAB POLYCOAT powder coated with media indication according to EN13792

Hose nozzle: Metal, fixed (can be unscrewed with Allen key, thread: male G3/8) or quick release coupling (hexagon coded)

Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

NON-BURNING 2.0 GASES VACUUM / HIGH FLOW **Headwork:** Needle Headwork: High flow **Opening/closing function: Opening/closing function:** 1.5 x 360°

3 x 360°

Max. working pressure: 16 bar / 232 psi

**Working pressure:** -1 bar to 16 bar /

-14.5 psi to 232 psi

# MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: PVDF Sealing: FKM

Lubricant: Perfluoropolyether based

# ORDERING INFORMATION


For standard configuration please refer to the item numbers below.

Other options:

- different media
- removable hose nozzle with union nut
- micro flow headwork (for 2.0 non-burning gases)
- high flow headwork (for 2.0 non-burning gases)
- alternative hose inlet connection / without a hose
- other inlet options (type, length)

/ledia	with fixed nozzle	with hexagon coded quick release coupling
(A) Compressed air	2532 164 1021-52B	2532 185 1021-52B
Nitrogen	2532 164 1023-52B	2532 185 1023-52B
Carbon dioxide	2532 164 1024-52B	2532 185 1024-52B
Argon	2532 164 1025-52B	2532 185 1025-52B
Helium	2532 164 1026-52B	2532 185 1026-52B
Low vacuum (1000 to 1 mbar)	2532 165 1028-52B	2532 193 1028-52B

For other options please refer to page 26 or contact your local BROEN-LAB representative.





Fittings with pressure regulator may only be used for the following non-burning 2.0 (99% pure) gases:

Compressed Air (CA), Nitrogen (N<sub>2</sub>), Carbon Dioxide (CO<sub>2</sub>) and Argon (Ar).

Not recommended for He. May NOT be used for Oxygen!

Handle on valves: Metal, BROEN-LAB POLYCOAT powder coated

with media indication according to EN13792

Handle on regulator: Plastic

Max. working pressure: 10 bar / 145 psi Allowable test pressure after installation:

1.5 x max working pressure without function of the valve

**SHUT-OFF VALVE NEEDLE VALVE** Headwork: High flow Headwork: High flow **Opening/closing function:** 

1.5 x 360° 3 x 360°

**Opening/closing function:** 

# MATERIALS WITH MEDIA CONTACT

Metals: Brass, zink **Plastics:** PVDF, POM

# **Sealings:**

- FKM (lubricated with perfluoropolyether based lubricant))
- NBR (lubricated with mineral oil based lubricant)

#### Model:





**Shut-off & Regulator & Needle** 

**Regulator & Needle** 

Item No.

2512 011 1021-14

2512 007 1021-14

Fittings are delivered with 1/2" ISO 7/1-R and female BROEN-LAB UniFlex™ connection. If you need another type of inlet please contact your sales representative.

The same item number can be applied to bench, wall or suspended models - just mention on the order how the fitting should be mounted. Fittings can be refitted on site as well.

For further information and mounting instructions please refer to www.BROEN-LAB.com or contact your local BROEN-LAB representative.

# BROEN-LAB-LAB UNIFLEX™ HOSES FOR NON-BURNING 2.0 GASES AND VACUUM



BROEN-LAB LAB offers BROEN-LAB UniFlex<sup>TM</sup> hoses as an easy way to make the installation in the laboratory where safety and efficiency are required. BROEN-LAB UniFlex<sup>TM</sup> hoses are the ideal solution where there is a higher requirement for flexibility. Installation with flexible hoses saves you time and labor - in other words reduced installation costs.


BROEN-LAB UniFlex $^{\text{TM}}$  hoses for non-burning 2.0 gases and vacuum are manufactured of soft cross-linked polyethylene (SPX). From the outside the hose is secured by a Stainless Steel braiding that ensures long service life and durability.

A wide range of fittings and lengths is available for BROEN-LAB UniFlex $^{\text{TM}}$  hoses enables customers to choose the perfect hose for their application.

Please request document No. 99G0005 for complete range of BROEN-LAB UniFlex™ hoses and technical specifications.

If you still prefer a standard way of installation with Cu, Stainless Steel, or PEX-pipes, BROEN-LAB LAB offers a wide range of connection fittings and adaptors for pipes of different dimensions.

Please request document No. 99G0004 for a complete range of BROEN-LAB UniFlex™ compression ring fittings.







OD12mm connection for compression fittings (Code 12)



OD1/2" connection for compression fittings (Code 13)



OD15mm connection for compression fittings (Code <mark>15</mark>)



OD15mm connection for press fittings (Code 65)



Straight BROEN-LAB UniFlex<sup>™</sup> connection with FKM O-ring (Code 20)



45° BROEN-LAB UniFlex<sup>™</sup> connection with FKM O-ring (Code 25)



90° BROEN-LAB UniFlex™ connection with FKM O-ring (Code 30)



# OUTLET CONNECTIONS 93TXX XX XXXX

Straight BROEN-LAB UniFlex™ connection with FKM O-ring (Code 20)



45° BROEN-LAB UniFlex<sup>™</sup> connection with FKM O-ring (Code 25)



90° BROEN-LAB UniFlex<sup>™</sup> connection with FKM O-ring (Code 30)



\*All O-rings are lubricated with perfluoropolyether based lubricant

# HOSE 93TXXXXXXXXXX

SPX hose with braiding in stainless steel



Marking for technical gases with Part no. and Media indication

# **HOSE LENGTHS**

Definition of length (L)



Definition of length (L)



If 45° and 90° elbows occur on the same hose, it will as default be mounted in U-form

# \*Standard lengths of hoses (L):

**0500** = 500mm

**0700** = 700mm

**1000** = 1000mm

**1200** = 1200mm

1500 = 1500mm

**2000** = 2000mm

2500 = 2500mm

**3000** = 3000mm

Length tolerance of hoses:  $L = \le 400 \text{mm} (-0, +10 \text{mm})$  L = 401 mm to 1000 mm (-0, +20 mm)L = >1000 mm (-0, +30 mm)

# SPECIFICATIONS

Inner hose material: SPX (soft PEX)

Braiding: Stainless steel with one

green stripe

**Materials with media contact:** PEX, brass, FKM and perfluoropolyether based lubricant

Inside diameter: 8.2mm

Outside diameter: 12mm

Max. working pressure: 16 bar

Max. working temperature: 90°C

Bending radius (inner): ≥ 40mm

Min. length with connections: 160mm

# EXAMPLE OF HOSE CONFIGURATION

1200mm hose with OD 12mm inlet connection and straight UniFlex™ outlet connection



93T12201200

<sup>\*</sup> Other lengths are available on request

BROEN-LAB UniFlex<sup>™</sup> fittings for non-burning 2.0 gases are as a standard delivered with needle headwork for fine regulation of media flow.

**Opening/closing function:** 3 x 360° turn **Media:** Non-burning 2.0 (99% clean) gases **Max. working pressure:** 16 bar / 232 psi **Test pressure:** 1.5 x working pressure



#### MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: PVDF Sealing: FKM


**Lubricant:** Perfluoropolyether based

#### ORDERING INFORMATION

**1. Green plastic ring** No. 0255035-5168

2. Needle headwork

No. 02557300



# HIGH FLOW HEADWORK

# **SPECIFICATIONS**

BROEN-LAB UniFlex™ fittings for vacuum are as a standard delivered with a high flow headwork. This headwork ensures high flow of media and can also be used for

other non-burning 2.0 gases.


**Opening/closing function:** 1.5 x 360° turn

Media: Vacuum and non-burning 2.0 (99% clean) gases

Working pressure: -1 to 16 bar / -14.5 to 232 psi

**Test pressure:** 1.5 x working pressure





#### MATERIALS WITH MEDIA CONTACT

Metals: Brass Plastics: PVDF Sealing: FKM

**Lubricant:** Perfluoropolyether based

# ORDERING INFORMATION


1. Grey plastic ring

No. 0255035-2696

2. High flow headwork

No. 02556300

### FLOW CHART




# **HEADWORKS**

# MICRO FLOW HEADWORK

#### **SPECIFICATIONS**

BROEN-LAB Micro flow headwork ensures very fine regulation of media where flow of gas is close to zero and microscopic flow rates are required.

**Opening/closing function:** 7.5 x 360° turn **Media:** Non-burning 2.0 (99% clean) gases **Max. working pressure:** 16 bar / 232 psi **Test pressure:** 1.5 x working pressure



#### MATERIALS WITH MEDIA CONTACT

Metals: Brass
Plastics: PVDF
Sealing: FKM


**Lubricant:** Perfluoropolyether based

#### ORDERING INFORMATION

# Micro flow headwork

No. 19154400

#### FLOW CHART



# 1/4-TURN HEADWORK

# **SPECIFICATIONS**

BROEN-LAB-LAB UniFlex TM PREMIUM fittings for non-burning 2.0 gases and vacuum can also be delivered with a 1/4-turn headwork (also recommended for disability friendly handle)

**Opening/closing function:** 90° turn

Media: Vacuum and non-burning 2.0 (99% clean) gases

Working pressure: -1 to 8 bar / -14.5 to 116 psi

**Test pressure:** 1.5 x working pressure

# MATERIALS WITH MEDIA CONTACT

Metals: Brass Sealing: FKM

**Lubricant:** Perfluoropolyether based

### ORDERING INFORMATION


#### 1/4-turn headwork

No. 19174100



Illustration	Description	BROEN-LAB item No.
<u> </u>	Adaptor for removable metal nozzle	2539 043 1021
	Removable metal nozzle	2539 008 1021
	Fixed metal nozzle	2539 042 1021
	Quick release coupling (hexagon coded)	19 632 00
	Pressure regulator	15 730 009
	Mounting set for G1/2 connection Mounting set for M30x1.5 connection	19 141 000 19 190 000
	G1/2 inlet with female BROEN-LAB UniFlex <sup>™</sup> connection (incl. O-ring)  L=30mm L=60mm L=90mm	15 504 33T 15 504 12T 15 504 46T
	Threaded inlet pipe M30x1,5 L=30mm L=60mm L=90mm	19 190 03 19 190 02 19 190 04
	Wall flange socket (for exposed piping)	02 101 30G
74mm 25mm Female BROEN-LAB UniFlex <sup>TM</sup>	Wall flange socket (for built-in installation)	02 101 31
Ø62.5mm	Cover flange for 02 101 31	1492304G
	Metal handle with media indication according to EN 13792	191601491021 (CA) 191601491023 (N <sub>2</sub> ) 191601491024 (CO <sub>2</sub> ) 191601491025 (Ar) 191601491026 (He) 191601491028 (V) 191601491029 (VF)

Generally, item number for BROEN-LAB UniFlex fittings has the following structure:



For installation with Cu- and Stainless Steel BROEN-LAB offers a wide range of connection fittings and adapters for pipes of different dimensions. Please request document No. 99G0004 for a complete range of BROEN-LAB UniFlex™ compression ring fit-

τ	J
ė	n
-	~
(	0
ř	Ŧ
4	
4	_
	ı.
r	
4	
t	D
	•
-	
-	
4	Z
	П
r	-
Ţ	п
١,	×
-	4
	2
	7
	П
-	-
-	4
	j
	7
-	7
4	_
(	
	43
(	Л
	_
-	П
(	$\neg$
-	
10	J
	_
4	Z
1	5
١	J
- 5	Z
	Τ
t	D
,	
- (	=
-	=
10	IJ
- 5	Ž
÷	=
4	_
	J
	4)
P	J
	_
6	0
- (	3
1	
1	Þ
Ü	'n
-	-
Ţ	U
(	Λ
1	<
4	Б
-	_
	٦
- (	i
-	
(	Ξ
-	
(	Ξ
(	
(	Ξ
(	
(	
(	

**NOTES** 

BROEN-LAB develops, manufactures and sells Laboratory Fittings, Emergency Shower Systems and Eye Wash Systems into a broad spectrum of laboratories and industrial locations; sectors include Pharmaceutical, Food&Beverage and Academia. Our expertise and product quality ensure optimal solutions compliant to all relevant international norms setting new standards in risk mitigation in modern research and development facilities.

BROEN-LAB offer solutions that ensure the functionality, compliance, hygiene, durability and safety are of the highest priority. For over 50 years our products have been integrated into a wide variety of workplaces, laboratories, hospitals and industrial locations, with features that are assessed and designed to be flexible, durable and compliant offering a broad range of options tailored to each location. This inherent design integrity provides confidence in the solution adopted wherever in the world these are applied.

BROEN-LAB is a collaboration partner in the design and layout of your next laboratory and it's integrated safety solutions

#### **HEAD OFFICE**

#### **BROEN-LAB A/S**

Drejervaenget 2 • DK-5610 Assens Denmark Tel.: +45 6376 6376 • Fax +45 6471 2476 E-mail: lab@broen.com



# **BROEN-LAB A/S ISO 9001 certification**

In September 1991 BROEN-LAB A/S was certified according to ISO 9001 as one of the first Danish companies. The certification was carried out by Bureau Veritas, Denmark, for our Danish site in Assens. The quality management system of BROEN-LAB A/S now complies with detailed specifications laid down by the internationally acknowledged EN ISO 9001:2015. This certification will further contribute to reputation for quality and reliability of BROEN-LAB A/S.

#### **INTERNATIONAL OFFICES**

#### **BROEN-LAB Ltd**

Tel. +44 121 522 4515 E-mail: lab@broen-lab.com

# **BROEN-LAB Singapore Pte. Ltd.**

25 International Business Park #04-60A German Centre Singapore 609916 Tel. +65 6298 0662 • Fax +65 6298 0468

E-mail: lab@broen-lab.com

#### **BROEN-LAB GmbH**

Tel.: +45 6376 6376 • Fax +45 6471 2476 E-mail: lab@broen-lab.com

#### **BROEN-LAB Sverige AB**

Tel.: +45 6376 6376 • Fax +45 6471 2476 E-mail: lab@broen-lab.com

#### **BROEN-LAB Inc.**

15 Constitution Drive Suite 122 Bedford • NH 03110 • USA Tel.: +1 603 310 5089 E-mail: lab@broen-lab.com

www.BROEN-LAB.com